

CONFIGURABLE SWING

IJSLANDER B.V.



IJSLANDER



01

NUMBER OF BAYS




02

UPRIGHT



03

SWING SEATS




04

BEARING



05

INSTALLATION



CONFIGURE YOUR OWN SWING





Step 01

Choose the number of bays with a maximum of 5 bays.



Step 02

Choose the material of the posts



Wood



Robinia



Standard



Plain stainless steel



Powdercoating
Any standard
RAL color



Carisma



Plain stainless steel



Powdercoating
Any standard
RAL color



Madera



Flat seat




SMALL SEATS



Toddler Seat

Synthetic basket



Rope basket



LARGE SEATS



Parent-child swing



Basket chair swing

Step 03

Fill the portals with the desired seats


Color options rope basket and basket chair swing






Step 04

Choose standard or anti-wrap bearings per seat





Is mounted 10 cm below ground level on a paved surface. After installation, a fall-absorbing surface can be applied.

Step 05

Choose the desired mounting

